



# KEYRING THERMOMETER



Operating Instructions

**INSTRUMENT OPERATION** - Install the battery with the positive terminal (+) facing upward. The thermometer will display the temperature instantly. Press the '⏻' button to turn off.

Open the steel probe and insert it into the test substance at least 25 mm (1 inch) deep. Wait for the reading to stabilise before taking the reading.

**BATTERY REPLACEMENT** - The battery is located at the rear of the instrument. Remove the battery cover with a coin and turn in the direction of the arrow. Replace battery with a LR44 button cell battery before re-tightening the battery cover.

**BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN.**

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.



**ERROR MESSAGE** - If the display shows 'LLL' the reading is outside of the lowest measurement range (-50 °C), or there is an open circuit in the sensor. If the display shows 'HHH' the reading is outside of the highest measurement range value (120 °C), or there is a short circuit in the sensor.

**GUARANTEE** - This instrument carries a one-year guarantee against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of ETI, be either repaired or replaced without charge. The product guarantee does not cover damage caused by fair wear and tear, abnormal storage conditions, incorrect use, accidental misuse, abuse, neglect, misapplication or modification. Full details of liability are available within ETI's Terms & Conditions of Sale at etilt.com. In line with our policy of continuous development, we reserve the right to amend our product specification without prior notice.



Supplied by  
Electronic Temperature Instruments Ltd  
Worthing · West Sussex · BN14 8HQ  
01903 202151 · sales@etiltd.com · etiltd.com

